

Installation Guide

ATF

Frost thermostat

Application

The ATF is a clamp-on pipe mounting frost thermostat. The thermostat is supplied complete with a spring fixing strap for use with pipework from ½ to 2".

Fixing the thermostat

- 1, Ensure that the pipe surface to which the thermostat is to be clamped is clean and free from paint and rust.
- 2, Place the thermostat on the pipe, securing one end of the spring fixing strap to one of the fixing lugs on the thermostat. Stretch the spring strap around the pipe and clip over the un-used fixing lug on the thermostat. It is important that the spring strap holds the thermostat tightly to the pipe. Cut off any surplus spring strap using a pair of side cutting pliers.
- 3, Remove the thermostat cover, take the flexible cord through the gland plate and terminate the core of the flexible lead on the appropriate terminals on the thermostat, noting that,
Terminal 1-2 : Break on rise of temperature
Terminal 1-4 : Break on fall of temperature
It is important that the product be earthed.

Setting the thermostat

Set at minimum 20°C


Technical specifications

Temperature range: 20-90°C
Switching Differential: 8K
Voltage rating: 220/240 Volts AC 50Hz
Current rating: 15 (2.5) Amp
Switching action: SPDT


Note:

This unit has been calibrated to switch on the temperature fall at the dial set value, in order to provide frost protection.

The unit must be installed by a competent electrician and the installation should conform for the current IEE Wiring Regulations. An Earth connection is required.



Wiring Detail:



1 - 2 : BREAK ON RISE
1 - 4 : BREAK ON FALL

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.
All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.